


# Chromebook Powerwash Instructions

1. Sign out of your Chromebook


Note: any data stored on the Chromebook's hard drive will be lost following the Powerwash

2. Press the key combination: ESC + Refresh + Power Button


3. On the **Please insert a recovery USB stick or SD card** screen, press **CTRL + D**



4. On the **To turn OS verification...** screen press ENTER




5. On the **OS verification is OFF** screen press **ENTER**



6. The Chromebook will restart


7. On the **Welcome** screen click **Let's Go**






8. On the **Connect to Network** select a WiFi network and click **Next**.


Note: if at a DDSB Network location select Ignite-Mobile if available.



9. Enter appropriate credentials to connect to WiFi and click **Connect**.




10. On the **Google Chrome OS terms** screen click **Accept and Continue**




11. The Chromebook will check for updates and may update at this time

12. Automatic Enterprise Enrollment to DDSB will occur.



13. At the **You are enrolled successfully** screen click **Done**



14. Your Chromebook is now Powerwashed and ready to use!

